



Plate deep  
Ø 225 mm (nr 2620)



Plate flat  
Ø 170 mm (nr 2628)  
Ø 190 mm (nr 2630)  
Ø 210 mm (nr 2631)  
Ø 240 mm (nr 2624)  
Ø 260 mm (nr 2636)  
Ø 270 mm (nr 2638)



Round dish  
Ø 305 mm (nr 2643)  
Ø 320 mm (nr 2669)



Oval dish  
Ø 240 mm (nr 2656)  
Ø 280 mm (nr 2668)  
Ø 330 mm (nr 2660)  
Ø 380 mm (nr 2662)



Pickle dish  
Ø 240 mm (nr 6112)



Salad bowl  
Ø 140 mm (nr 2614)  
Ø 185 mm (nr 2619)  
Ø 230 mm (nr 2623)



Bouillon cup with handles and saucer  
0,30 l / Ø 170 mm (nr 2616, 2615)



Cup and saucer  
0,10 l / Ø 135 mm (nr 2670, 2672)  
0,19 l / Ø 160 mm (nr 2606, 2613)



Mug  
0,30 l (nr 2610)



Gravy boat  
0,40 l (nr 2680)



Milk jug  
0,15 l (nr 6003)  
0,30 l (nr 2605)



Tea pot  
0,40 l (nr 6020)  
1,40 l (nr 2626)



Coffee pot  
0,30 l (nr 2673)  
0,60 l (nr 2674)  
1,00 l (nr 2676)  
1,35 l (nr 2677)



Soup tureen  
2,70 l (nr 2664)



Sugar bowl  
0,25 l (nr 2679)



Bowl  
0,06 l (nr 2699)



Napkin holder  
(nr 2688)



Ashtray  
Ø 100 mm (nr 2622)



Salt shaker  
(nr 2685)



Pepper shaker  
(nr 2686)



Egg cup  
(nr 2687)