

# VICTORIA



Plate deep  
 Ø 215 mm (nr 2719)  
 Ø 230 mm (nr 2720)



Plate flat square  
 Ø 155 mm (nr 2727)  
 Ø 170 mm (nr 2728)  
 Ø 190 mm (nr 2730)  
 Ø 210 mm (nr 2731)  
 Ø 260 mm (nr 2736)  
 Ø 280 mm (nr 2738)  
 Ø 320 mm (nr 2769)



Rectangular dish  
 Ø 280 mm (nr 2760)  
 Ø 320 mm (nr 2758)  
 Ø 380 mm (nr 2762)



Pickle dish  
 Ø 240 mm (nr 7112)



Salad bowl  
 Ø 130 mm (nr 2714)  
 Ø 180 mm (nr 2718)  
 Ø 230 mm (nr 2723)



Bouillon cup with saucer  
 0,30 l / Ø 170 mm (nr 2716, 2724)  
 0,40 l / Ø 170 mm (nr 2741, 2724)



Bouillon cup with saucer  
 HOTEL  
 0,32 l / Ø 170 mm (nr 2817, 2816)



Cup and saucer  
 HOTEL  
 0,08 l / Ø 125 mm (nr 2870, 2871)  
 0,19 l / Ø 155 mm (nr 2806, 2815)  
 0,16 l / Ø 155 mm (nr 2800, 2815)



Dessert plate  
 Ø 260 mm (nr 2825)



Cup and saucer  
 0,28 l / Ø 170 mm (nr 2703, 2717)



Cup and saucer  
 0,09 l / Ø 115 mm (nr 2770, 2771)  
 0,20 l / Ø 145 mm (nr 2706, 2713)  
 0,25 l / Ø 145 mm (nr 2702, 2713)



Cup and saucer  
 0,22 l / Ø 145 mm (nr 2701, 2713)  
 0,24 l / Ø 145 mm (nr 2700, 2713)



Mug  
 0,30 l (nr 2710)  
 0,35 l (nr 2740)



Mug and saucer  
 0,50 l / Ø 160 mm (nr 2740, 2711)



Jug  
 0,05 l (nr 2805)



Milk jug  
 0,15 l (nr 2704)  
 0,30 l (nr 2705)



Gravy boat  
 0,40 l (nr 2782)



Tea pot  
 0,40 l (nr 2722)  
 1,00 l (nr 2721)



Coffee pot  
 0,30 l (nr 2763)  
 1,35 l (nr 2777)



Soup tureen  
 2,70 l (nr 2764)



Side dish  
 1/4 (nr 2897)




Bowl  
 0,20 l (nr 2807)  
 0,10 l (nr 2808)



Sugar bowl  
 0,30 l (nr 2779)



Sugar bowl  
 0,30 l (nr 2789)



Egg saucer  
 115 mm (nr 2787)



Pickle dish  
 210 mm (nr 2899)



Vase  
 120 mm (nr 2887)  
 160 mm (nr 2898)



Candlestick  
 130 mm (nr 2766)



Napkin holder  
 (nr 2792)



Salt shaker  
 (nr 2785)



Pepper shaker  
 (nr 2786)