



Plate deep
Ø 225 mm (nr 2420)



Plate flat
Ø 165 mm (nr 2428)
Ø 190 mm (nr 2430)
Ø 210 mm (nr 2431)
Ø 225 mm (nr 2432)
Ø 250 mm (nr 2436)
Ø 270 mm (nr 2438)
Ø 305 mm (nr 2443)



Oval dish
Ø 290 mm (nr 2458)
Ø 330 mm (nr 2460)



Pickle dish
Ø 240 mm (nr 2408)



Salad bowl
Ø 130 mm (nr 2414)
Ø 165 mm (nr 2418)
Ø 180 mm (nr 2419)
Ø 230 mm (nr 2423)



Bowl
Ø 140 mm (nr 2424)



Tea pot
0,40 l (nr 2422)



Coffee pot
0,30 l (nr 2473)



Sugar bowl
0,20 l (nr 2479)



Milk jug
0,05 l (nr 2001)
0,15 l (nr 2405)
0,30 l (nr 2003)



Milk jug
0,05 l (nr 2001)



Cup and saucer
0,16 l / Ø 145 mm (nr 2401, 2412)
0,19 l / Ø 145 mm (nr 2407, 2412)
0,22 l / Ø 145 mm (nr 2406, 2412)



Cup and saucer
0,08 l / Ø 130 mm (nr 2470, 2472)



Cup and saucer
0,10 l / Ø 130 mm (nr 2480, 2472)



Cup and saucer
0,21 l / Ø 145 mm (nr 2403, 2412)



Mug
0,30 l (nr 2410)



Bouillon cup and saucer
0,22 l / Ø 145 mm
(nr 2421, 2412)



Bouillon cup and saucer
0,30 l / Ø 165 mm
(nr 2416, 2415)



Bouillon cup with handles and saucer
0,32 l / Ø 165 mm
(nr 2417, 2415)